BLOOM
aroma diffuser user manual



ESCENTS®

www.escents.ca
1.800.964.1150

OPERATION

BUTTON OPERATION

1st press: Mist continuously with indicator light on
2nd press: Interval mist with indicator light blinking
3rd press: Turn off

Press and hold for 2 seconds to turn indicator light off.

POWER OPTIONS

AA batteries x 4

Use rechargeable batteries if possible.

USB adaptor
DC 5V ⎓ 850-1000mA

Size:	112 mm x 97 mm
Weight:	400g
Input:	DC 5V⎓850-1000mA
Output:	DC 5V 1A
Outer casing:	White Plastic
Accessories:	USB AC adaptor, USB cable



1. Remove cover.

2. Fill water tank to indicated water line.

3. Add 3-5 drops of your favourite Escents essential oil or aroma blend to the water.



4. Replace cover.

5. Turn on diffuser.



note: Do not lean, move, attempt to empty, or refill during operation.

TROUBLESHOOTING

symptom	possible cause	solution
no mist	indicator light blinking fast	battery power low; replace or plug in
	bubbles appearing on oscillator disc	wipe disc and refill water tank
	insufficient water	refill water tank
	water exceeds the max water level line	dump out excess water
	mist outlet is blocked	clean outlet and keep it ventilated

MISCELLANEOUS

Always fill with tap water at room temperature.

If diffuser is knocked over during operation, liquid may flow into the internal mechanism. Empty out water and let stand in a well ventilated area for at least 3 days to dry if this occurs.

If any further problems occur, please contact Escents customer service. 1.800.964.1150 or at sales@escents.ca.

BLOOM
diffuseur d'arôme manuel d'instructions



ESCENTS®

www.escents.ca
1.800.964.1150

FONCTIONNEMENT

FONCTIONNEMENT DES BOUTONS

1 presse: Brume en continu avec voyant lumineux.

2 presse: Brume intervalle avec voyant lumineux clignotant.

3 presse: Éteindre

Appuyez et maintenez pendant 2 secondes pour éteindre voyant lumineux.

OPTIONS D'ALIMENTATION

Batteries d'AA x 4

Utiliser rechargeable batteries si possible.

Adaptateur USB

DC 5V ⎓ 850-1000mA

Dimension: _____ 112 mm x 97 mm
Poids: _____ 400g
Énergie: _____ DC 5V⎓ 850-1000mA
Production: _____ DC 5V 1A
Enveloppe Extérieure: _____ Plastique Blanc
Accessoires: ___Adaptateur secteur USB, Câble USB



1. Retirer le couvercle.

2. Remplir le réservoir d'eau de la ligne d'eau indiquée.

3. Ajouter 3-5 gouttes d' vos Escents préférés huile essentiel se mélangent à l'eau.



4. Remettre le couvercle.

5. Allumer diffuseur.



note: Ne pas se pencher, déplacer, tentative de vider, ou remplir pendant le fonctionnement.

DÉPANNAGE

symptôme	cause possible	solution
pas de brume	voyant lumineux clignote rapidement	batterie faible puissance; remplacer ou de brancher
	bulles apparaissant sur le disque oscillateur	essuyez disque et remplir le réservoir d'eau
	manque d'eau	remplir le réservoir d'eau
	l'eau dépasse la ligne de niveau d'eau maximum	vider l'eau en excès
	sortie brume est bloqué	sortie propre et garder ventilé

MISCELLANEOUS

Toujours remplir avec de l'eau du robinet à température ambiante.

Si le diffuseur est renversé lors du fonctionnement, du liquide peut S'écouler dans le mécanisme interne. Vider l'eau et laisser reposer dans un endroit bien aéré pendant au moins 3 jours à sécher si cela se produit.

Si d'autres problèmes surviennent, s'il vous plaît contacter le service client Escents. 1.800.964.1150 ou à sales@escents.ca.